

# Working Instructions

## - mechanical -



*Xperia Z1™*  
**C6902, C6903, C6906, L39h**

## CONTENTS

<b>1</b>	<b>Exterior Views.....</b>	<b>5</b>
1.1	C6902, C6903, C6906, L39h .....	5
<b>2</b>	<b>Tools .....</b>	<b>6</b>
<b>3</b>	<b>Disassembly.....</b>	<b>8</b>
3.1	Window Back and Sheet Battery.....	8
3.2	Rear Cover Assy .....	10
3.3	Camera.....	12
3.4	Shield Camera .....	12
3.5	SIM Tray .....	13
3.6	Battery.....	13
3.7	Main PBA .....	14
3.8	Loudspeaker Holder.....	16
3.9	RF Cable A.....	17
3.10	Main Frame Assy and Front Cover .....	17
<b>4</b>	<b>Replacement .....</b>	<b>19</b>
4.1	Window Back.....	19
4.2	Sheet Battery .....	19
4.3	Rear Cover Assy .....	19
4.4	Camera.....	19
4.5	Shield Camera .....	20
4.6	SIM Tray .....	20
4.7	Battery.....	20
4.8	Loudspeaker Holder.....	20
4.9	RF Cable A.....	21
4.10	Main Frame Assy.....	21
4.11	Adhesive Earspeaker .....	22
4.12	Adhesive FPC Relay Bottom .....	23
4.13	Adhesive WP Audio Jack .....	24
4.14	Adhesive WP Camera Key .....	25
4.15	Adhesive WP Cover Rear .....	26
4.16	Adhesive WP Loudspeaker .....	27
4.17	Adhesive WP Main Frame Assy .....	28
4.18	Adhesive WP Side Key .....	30
4.19	Adhesive WP Window Back .....	31
4.20	BT + WLAN Flex Antenna .....	33
4.21	Camera Holder.....	34
4.22	Camera Key .....	35
4.23	Chat Camera.....	36
4.24	Chat Camera Holder.....	37

4.25 Core Unit Label.....	38
4.26 Cushion 1 <sup>st</sup> Mic.....	39
4.27 Cushion 2 <sup>nd</sup> Mic.....	40
4.28 Ear Speaker .....	41
4.29 FPC Assembly Audio Jack.....	42
4.30 FPC Assembly Charger .....	43
4.31 FPC Assembly Mic .....	44
4.32 FPC Assembly Relay.....	45
4.33 Front Cover.....	46
4.34 Gasket Charger .....	47
4.35 Gasket Side Key.....	48
4.36 Holder Magnetic Charger Connector .....	49
4.37 Liquid indicator .....	50
4.38 Loudspeaker.....	51
4.39 Magnetic charger connector .....	52
4.40 PBA Cellular Sub.....	53
4.41 PBA WLAN Sub .....	54
4.42 Plate Contact RF A.....	55
4.43 Power Key.....	56
4.44 RF Cable B.....	57
4.45 SD Cap .....	58
4.46 Sheet Conductive Charger FPC .....	59
4.47 Sheet Conductive Relay FPC .....	60
4.48 Sheet Thermal A.....	61
4.49 Sheet Thermal B.....	62
4.50 Sheet WP 2 <sup>nd</sup> Mic.....	63
4.51 Sheet WP Check.....	64
4.52 SIM Cap.....	65
4.53 Speaker Panel.....	66
4.54 Tray Core Unit Label .....	67
4.55 USB Cap.....	68
4.56 USB Holder .....	69
4.57 Vibrator .....	70
4.58 Volume Key .....	71
4.59 Board Swap - Replacement .....	72
<b>5 Re-Assembly.....</b>	<b>73</b>
5.1 Front Cover and Main Frame Assy .....	73
5.2 RF Cable A.....	74
5.3 Loudspeaker Holder.....	74
5.4 Main PBA .....	75
5.5 Battery.....	76

5.6 SIM Tray ..... 76

5.7 Shield Camera ..... 77

5.8 Camera..... 77

5.9 Rear Cover Assy ..... 78

5.10 Sheet Battery ..... 80


5.11 Window Back..... 80

6 Revision History ..... 82

For general information about mechanical repair related issues, refer to  
1220-1333: Generic Repair Manual - mechanical

## 1 Exterior Views

### 1.1 C6902, C6903, C6906, L39h




## 2 Tools

### SPECIAL TOOLS

1. Torque Screwdriver
2. Front Opening Tool
3. Torx Bits T4
4. Flex Film Assembly Tool
5. Guitar Pick


6. Front Cover Adhesive fixture
7. Rear Cover Adhesive fixture
8. Window Back Adhesive fixture
9. Rear Cover Press Inlay
10. Window Back Press Inlay
11. Bottom Press Inlay

12. Press Tool Earspeaker
13. Press Tool Loudspeaker
14. Audio Jack press



## Tools


- 15. Side Panel press
- 16. Side Panel Press Head
- 17. Charge connector press pad



**For part not on the tools above, refer to the 'Tools Catalogue/Matrix'!**

### STANDARD TOOLS

- 1. Dentist Hook
- 2. Nylon Pointer
- 3. Tweezer



- 4. Suction cup




## 3 Disassembly

### C6902, C6903, C6906, L39h

The Disassembly is done to the following modules:

1. Window Back (a) and Sheet Battery (b)
2. Rear Cover Assy
3. Camera
4. Shield Camera
5. SIM Tray
6. Battery
7. Main PBA
8. Loudspeaker Holder
9. RF Cable A
10. Main Frame Assy (a) and Front Cover (b)



### 3.1 Window Back and Sheet Battery




Use Suction cup to get space for inserting the Guitar Pick.





## Disassembly

Gently slide the Guitar Pick along to release all sides of the Back Panel Assy.


**Note! Start in the middle of the right long side!**



**Note! Be careful not to damage flexes when using plectrum on the top of phone!**



## Disassembly



Remove the Window Back by using the Suction cup.

**Note!** Be careful when removing the Window back due to the adhesive between battery and Window Back.




### 3.2 Rear Cover Assy


Remove the nine Screw 3.5x1.4 by using a screwdriver with Torx Bits T4.

## Disassembly


Use a plectrum to detach right side and the top of the phone




Use a plectrum to detach left side and the bottom of the phone



Use a Front Opening Tool to disconnect the BtB connector.




Remove the Rear Cover Assy with fingers




## Disassembly

Use a Front Opening Tool to disconnect the BtB connector.




### 3.3 Camera

Use a Front Opening Tool to disconnect the BtB connector.




Remove the Camera with fingers.




### 3.4 Shield Camera

Remove the Shield Camera with fingers.




## Disassembly

Remove it.




### 3.5 SIM Tray

Open SIM Cap.



Remove the SIM Tray with fingers.



### 3.6 Battery

Remove the Battery with fingers.


Carefully inspect the Battery after removing it.  
Battery with visual signs of been punctured etc. should be scraped after removal!




## Disassembly

### 3.7 Main PBA


Use a Front Opening Tool to disconnect the Cable RF B




Use a Front Opening Tool to disconnect the Cable RF A



Use a Front Opening Tool to disconnect the FPC Assembly Charge




Use a Front Opening Tool to disconnect the FPC Assembly Audio Jack





## Disassembly

Use a Front Opening Tool to disconnect the Vibrator




Use a Front Opening Tool to disconnect the FPC Assembly Relay



Use a Front Opening Tool to lift up the Main PBA.




Use a Front Opening Tool to lift up the Main PBA.




## Disassembly

Remove the Main PBA with fingers




### 3.8 Loudspeaker Holder


Use a Front Opening Tool to disconnect the Cable RF B



Use a Front Opening Tool to disconnect the Cable RF A




Use a Front Opening Tool to lift up the Loudspeaker Holder.






## Disassembly

Remove the Loudspeaker Holder with fingers.





### 3.9 RF Cable A

Use a pair of tweezers to remove the RF Cable A





### 3.10 Main Frame Assy and Front Cover

Use Suction cup to get space for inserting the Guitar Pick. Gently slide the Guitar Pick along to release all sides of the Main Frame Assy.



## Disassembly



Remove the Front Cover from Main Frame Assy

## 4 Replacement

### 4.1 Window Back

Follow the 3.1 Disassembly instructions!

**Note! If reuse of Window Back follow 4.19 Removal Instruction**

Prepare a new Window Back.

**Note! If reuse of Window Back follow 4.19 Installation Instruction**

Follow the 5.11 Reassembly instructions!



### 4.2 Sheet Battery

Follow the 3.1 Disassembly instructions and use a Flex Film Assembly Tool for removing it from Window Back!

Prepare a new Sheet Battery

Follow the 5.10 and 5.11 Reassembly instructions!



### 4.3 Rear Cover Assy

Follow the 3.1 and 3.2 Disassembly instructions!

**Note! If reuse of Rear Cover Assy follow 4.15 Removal Instruction**

Prepare a new Rear Cover Assy.

**Note! If reuse of Rear Cover Assy follow 4.15 Installation Instruction**

Follow the 5.9 - 5.11 Reassembly instructions!




### 4.4 Camera

Follow the 3.1- 3.3 Disassembly instructions!

Prepare a new Camera.

Follow the 5.8 - 5.11 Reassembly instructions!



## Replacement

### 4.5 Shield Camera

*Follow the 3.1 - 3.5 Disassembly instructions!*

Prepare a new Shield Camera.

*Follow the 5.7 - 5.11 Reassembly instructions!*




### 4.6 SIM Tray

*Follow the 3.5 Disassembly instructions!*

Prepare a new SIM Tray.

*Follow the 5.6 Reassembly instructions!*



### 4.7 Battery

*Follow the 3.1-3.2 and 3.6 Disassembly instructions!*

Prepare a new Battery.

*Follow the 5.5 and 5.9-5.11 Reassembly instructions!*



### 4.8 Loudspeaker Holder

*Follow the 3.1 – 3.2, 3.6 and 3.8. Disassembly instructions!*

*Follow the 4.38, 4.40 and 4.41 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Loudspeaker Holder*

*Carry out the Installation as described below!*

*Follow the 4.38, 4.40 and 4.41 Installation instructions!*

*Follow the 5.3, 5.5 and 5.9 - 5.11 Reassembly instructions!*




## Replacement

### 4.9 RF Cable A

*Follow the 3.1 - 3.2, 3.6 and 3.9 Disassembly instructions!*

Prepare a new RF Cable A.

Follow the 5.2, 5.5 and 5.9-5.11 Reassembly instructions!



### 4.10 Main Frame Assy


*Follow the 3.1-3.10 Disassembly instructions!*

**Note! If reuse of Main Frame Assy follow 4.17 Removal Instruction**

Prepare a new Main Frame Assy.

**Note! If reuse of Main Frame Assy follow 4.17 Installation Instruction**

Follow the 5.1-5.11 Reassembly instructions!



## Replacement

### 4.11 Adhesive Earspeaker

*Follow the 3.1 – 3.7 Disassembly instructions!*

*Follow the 4.28 Removal instructions!*

*Carry out the Removal as described below!*

*Prepare a new Adhesive Earspeaker!*

*Carry out the Installation as described below!*



*Follow the 4.28 Installation instructions!*

*Follow the 5.4 - 5.11 Reassembly instructions!*

#### REMOVAL


Detach to remove the Adhesive Earspeaker with the Dentist Hook.

**Scrap! Not to be reused!**



#### INSTALLATION

Place a new Adhesive Earspeaker using a Flex Film Assembly Tool.



## Replacement

### 4.12 Adhesive FPC Relay Bottom

*Follow the 3.1 – 3.10 Disassembly instructions!*

*Follow the 4.32 Removal instructions!*

*Carry out the Removal as described below!*

*Prepare a new Adhesive FPC Relay Bottom!*

*Carry out the Installation as described below!*

*Follow the 4.32 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*


#### REMOVAL

Detach to remove the Adhesive FPC Relay Bottom with a pair of tweezers.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Adhesive FPC Relay Bottom using a Flex Film Assembly Tool.



## Replacement

### 4.13 Adhesive WP Audio Jack

*Follow the 3.1 – 3.10 Disassembly instructions!*

*Follow the 4.29 Removal instructions!*

*Carry out the Removal as described below!*

*Prepare a new Adhesive WP Audio Jack!*

*Carry out the Installation as described below!*

*Follow the 4.29 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Remove the Adhesive WP Audio Jack with the Flex Film Assembly Tool.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Adhesive WP Audio Jack with Flex Film Assembly Tool.





## Replacement

### 4.14 Adhesive WP Camera Key

*Follow the 3.1 – 3-10 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Adhesive WP Camera Key!*

*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*

#### REMOVAL

Detach to remove the Gasket Camera Key with the Flex Film Assembly Tool.





**Note! Please be careful when disassembly because this gasket needs to be reused!**

Detach to remove the Adhesive WP Camera Key with the Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Adhesive WP Camera Key on the Main Frame Assy using a Flex Film Assembly Tool.



## Replacement

### 4.15 Adhesive WP Cover Rear

*Follow the 3.1 and 3.2 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Adhesive WP Cover Rear!*

*Carry out the Installation as described below!*

*Follow the 5.9 - 5.11 Reassembly instructions!*

#### REMOVAL

Remove the Adhesive WP Cover Rear with fingers.





**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Adhesive WP Cover Rear with fingers in the Rear Cover Adhesive fixture (Bottom Part).

Then place the old Rear Cover Assy above Adhesive WP Cover Rear **Important to make sure that old adhesive is removed before installation because of WRT requirement!**

Place the Upper part of the fixture and press by hand for 10 sec



## Replacement

### 4.16 Adhesive WP Loudspeaker

*Follow the 3.1 – 3.2, 3.6 and 3.8. Disassembly instructions!*

*Follow the 4.38 Removal instructions!*

*Carry out the Removal as described below!*

*Prepare a new Adhesive WP Loudspeaker!*

*Carry out the Installation as described below!*

*Follow the 4.38 Installation instructions!*

*Follow the 5.3, 5.5 and 5.9 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Adhesive WP Loudspeaker with a Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Adhesive WP Loudspeaker by using a Flex Film Assembly Tool.



## Replacement



### 4.17 Adhesive WP Main Frame Assy

*Follow the 3.1 - 3.10 Disassembly instructions!  
Carry out the Removal as described below!  
Prepare a new Adhesive WP Main Frame Assy!  
Carry out the Installation as described below!  
Follow the 5.1 - 5.11 Reassembly instructions!*

#### REMOVAL

Remove the Adhesive WP Main Frame Assy with fingers.

**Scrap! Not to be reused!**



#### INSTALLATION

Take the Bottom Part of the Main Frame Assy Adhesive fixture



Place a new Adhesive WP Main Frame Assy with fingers in the Main Frame Assy Adhesive fixture (Bottom Part)




## Replacement

Then place the old Main Frame Assy above the Adhesive WP Main Frame Assy

Important to make sure that old adhesive is removed before installation because of WRT requirement!



Place the Upper part of the fixture and press by hand for 10 sec



## Replacement

### 4.18 Adhesive WP Side Key

*Follow the 3.1 - 3.10 Disassembly instructions!*

*Follow the 4.35 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Adhesive WP Side Key!*

*Carry out the Installation as described below!*

*Follow the 4.35 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Adhesive WP Side Key with the Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Adhesive WP Side Key on the Main Frame Assy using a Flex Film Assembly Tool.



## Replacement



### 4.19 Adhesive WP Window Back

*Follow the 3.1 Disassembly instructions!*  
*Carry out the Removal as described below!*  
*Prepare a new Adhesive WP Window Back!*  
*Carry out the Installation as described below!*  
Follow the 5.10 and 5.11 Reassembly instructions!

#### REMOVAL

Remove the Adhesive WP Window Back with fingers.

**Scrap! Not to be reused!**



#### INSTALLATION

Take the Bottom Part of the Window Back Adhesive fixture




Place a new Adhesive WP Window Back with fingers in the Window Back Adhesive fixture (Bottom Part)




## Replacement

Then place the old Window Back above the Adhesive WP Window Back

Important to make sure that old adhesive is removed before installation because of WRT requirement!



Place the Upper part of the fixture and press by hand for 10 sec





## Replacement

### 4.20 BT + WLAN Flex Antenna

*Follow the 3.1 Disassembly instructions!*

*Carry out the Removal as described below!*



*Prepare a new BT + WLAN Flex Antenna!*

*Carry out the Installation as described below!*

Follow the 5.10 and 5.11 Reassembly instructions!


#### REMOVAL

Remove the BT + WLAN Flex Antenna with the Flex Film Assembly Tool.



#### INSTALLATION

Place a new BT + WLAN Flex Antenna with fingers.



## Replacement

### 4.21 Camera Holder




*Follow the 3.1 - 3.3 Disassembly instructions!*  
*Carry out the Removal as described below!*  
*Prepare a new Camera Holder!*  
*Carry out the Installation as described below!*  
Follow the 5.8 - 5.11 Reassembly instructions!

#### REMOVAL

Remove the Camera Holder with fingers.

#### INSTALLATION

Attach the Camera Holder with fingers.



## Replacement

### 4.22 Camera Key


*Follow the 3.1 – 3.10 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Camera Key!*

*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Pull to remove the Camera Key with fingers

#### INSTALLATION

Insert a new Camera Key with fingers



## Replacement

### 4.23 Chat Camera

*Follow the 3.1 - 3.7 Disassembly instructions!*

*Carry out the Removal as described below!*


*Prepare a new Chat Camera!*

*Carry out the Installation as described below!*


*Follow the 5.4 - 5.11 Reassembly instructions!*

#### REMOVAL

Open the Zif contact with a Nylon pointer.




Use the Flex Film Assembly Tool to loosen the Chat Camera flex then use the Front Opening Tool to remove the Chat Camera.



#### INSTALLATION

Use the Flex Film Assembly Tool and attach the flex to Zif contact. Then use fingers for position the new Chat Camera in the cavity.



## Replacement

### 4.24 Chat Camera Holder

*Follow the 3.1 - 3.7 Disassembly instructions!*

*Carry out the Removal as described below!*


*Prepare a new Chat Camera Holder!*

*Carry out the Installation as described below!*

*Follow the 5.4 - 5.11 Reassembly instructions!*

#### REMOVAL

Remove the Chat Camera Holder with fingers.



#### INSTALLATION

Attach a new Chat Camera Holder with fingers.



## Replacement

### 4.25 Core Unit Label

*Carry out the Removal as described below!*

*Prepare a new Core Unit Label!*


*Carry out the Installation as described below!*

#### REMOVAL

Open SIM Cap with fingers



Pull out the Tray Core Unit Label with fingers and remove the label with a Dentist Hook.



#### INSTALLATION

Attach a new Core Unit Label with fingers on the Tray Core Unit Label. Close the SIM Cap.



## Replacement

### 4.26 Cushion 1<sup>st</sup> Mic


*Follow the 3.1 – 3-10 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Cushion 1<sup>st</sup> Mic!*

*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Remove the Cushion 1<sup>st</sup> Mic with Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Attach a new Cushion 1<sup>st</sup> Mic with the Flex Film Assembly Tool.



## Replacement

### 4.27 Cushion 2<sup>nd</sup> Mic

*Follow the 3.1 - 3.2 Disassembly instructions!*

*Follow the 4.31 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Cushion 2<sup>nd</sup> Mic!*

*Carry out the Installation as described below!*

*Follow the 4.31 Installation instructions!*

*Follow the 5.9 - 5.11 Reassembly instructions!*




#### REMOVAL

Remove the Cushion 2<sup>st</sup> Mic with Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Attach a new Cushion 2<sup>st</sup> Mic with the Flex Film Assembly Tool.





## Replacement

### 4.28 Ear Speaker

*Follow the 3.1 – 3.7 Disassembly instructions!*

*Follow the 4.11 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Ear Speaker!*

*Carry out the Installation as described below!*

*Follow the 4.11 Installation instructions!*


*Follow the 5.4 - 5.11 Reassembly instructions!*



#### REMOVAL

Remove the Ear Speaker using Front Opening Tool.


**Scrap! Not to be reused!**



#### INSTALLATION

Place a new Ear Speaker with fingers

Use Press Tool Earspeaker and press for 10s.



## Replacement

### 4.29 FPC Assembly Audio Jack


*Follow the 3.1 – 3.10 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new FPC Assembly Audio Jack!*


*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the FPC Assembly Audio Jack with fingers.




#### INSTALLATION

Place a new FPC Assembly Audio Jack with fingers.



Use Audio Jack Press and press for 10s.



## Replacement

### 4.30 FPC Assembly Charger

*Follow the 3.1 – 3.10 Disassembly instructions!*

*Follow the 4.46 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new FPC Assembly Charger!*

*Carry out the Installation as described below!*

*Follow the 4.46 Installation instructions!*


*Follow the 5.1 - 5.11 Reassembly instructions!*



#### REMOVAL


Remove the FPC Assembly Charger with the Flex Film Assembly Tool.

**Not! Be very careful because flex could be reused if no damage!**



#### INSTALLATION

Start by placing the buttons of the new FPC Assembly Charger with a Flex Film Assembly Tool before assembly the flex.



## Replacement

### 4.31 FPC Assembly Mic


*Follow the 3.1 – 3.2 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new FPC Assembly Mic!*

*Carry out the Installation as described below!*


*Follow the 5.9 - 5.11 Reassembly instructions!*



#### REMOVAL

Detach to remove the FPC Assembly Mic with the Flex Film Assembly Tool and fingers.


**Scrap! Not to be reused!**



#### INSTALLATION

Place a new FPC Assembly Mic using a Flex Film Assembly Tool.

**Note! Press for 10s to activate the adhesive around microphone**



## Replacement

### 4.32 FPC Assembly Relay

*Follow the 3.1-3.10 Disassembly instructions!*

*Follow the 4.47 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new FPC Assembly Relay!*

*Follow the 4.47 Installation instructions!*

*Carry out the Installation as described below!*


*Follow the 5.1 - 5.11 Reassembly instructions!*



#### REMOVAL


Start by disconnect the BtB connector against Display flex.  
Then remove the FPC Assembly Relay with the Flex Film Assembly Tool.

**Not! Be very careful because flex could be reused if no damage!**



#### INSTALLATION

Start by placing the buttons of the new FPC Assembly Relay with a Flex Film Assembly Tool before assembly the flex.  
Connect BtB connector against Display flex.



## Replacement

### 4.33 Front Cover

*Follow the 3.1 - 3.10 Disassembly instructions!*

*Follow the 4.22, 4.28, 4.30, 4.32 and 4.54 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Front Assembly!*

*Carry out the Installation as described below!*

*Follow the 4.22, 4.28, 4.30, 4.32 and 4.54 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*



## Replacement

### 4.34 Gasket Charger

*Follow the 3.1- 3.10 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Gasket Charger!*

*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Gasket Charger with a Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Gasket Charger using a Flex Film Assembly Tool.



## Replacement

### 4.35 Gasket Side Key

*Follow the 3.1- 3.10 Disassembly instructions!*

*Follow the 4.18 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Gasket Side Key!*

*Carry out the Installation as described below!*

*Follow the 4.18 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Remove the Gasket Side Key with the Flex Film Assembly Tool.

#### INSTALLATION

Place a new Gasket Side Key using a Flex Film Assembly Tool.





## Replacement

### 4.36 Holder Magnetic Charger Connector


*Follow the 3.1 - 3.6 and 3.9 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Holder Magnetic Charger Connector!*

*Carry out the Installation as described below!*

Follow the 5.2, 5.5 and 5.9-5.11 Reassembly instructions!




#### REMOVAL

Detach to remove Holder Magnetic Charger Connector with a pair of tweezers.

#### INSTALLATION

Place a new Holder Magnetic Charger Connector using a pair of tweezers.




## Replacement

### 4.37 Liquid indicator

*Carry out the Removal as described below!*

*Prepare a new Liquid indicator!*

*Carry out the Installation as described below!*




#### REMOVAL

Detach to remove the Liquid indicator with a Dentist Hook

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Liquid indicator follow the guiding lines on the Rear Cover Assy using a Front Assembly Tool.



## Replacement

### 4.38 Loudspeaker

*Follow the 3.1 – 3.2, 3.6 and 3.8 Disassembly instructions!*

*Follow the 4.16 Removal instructions!*

*Carry out the Removal as described below!*

*Prepare a new Loudspeaker!*

*Carry out the Installation as described below!*




*Follow the 4.16 Installation instructions!*

*Follow the 5.3, 5.5 and 5.9 - 5.11 Reassembly instructions!*

#### REMOVAL

Detach to remove the Loudspeaker with the Front Opening Tool.

**Scrap! Not to be reused!**




#### INSTALLATION

Place a new Loudspeaker by using fingers

Press to secure its attachment by using Press Tool Loudspeaker for five seconds.

**Do not touch the contact pins!**



## Replacement

### 4.39 Magnetic charger connector

*Follow the 3.1 - 3.6 and 3.9 Disassembly instructions!*

*Follow the 4.36 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Magnetic charger connector!*

*Carry out the Installation as described below!*

*Follow the 4.36 Installation instructions!*

*Follow the 5.2, 5.5 and 5.9-5.11 Reassembly instructions!*




#### REMOVAL

Push the two pads of *Magnetic charger connector* by using Flex Film Assembly Tool.


**Scrap! Not to be reused!**

**Be careful! Do not damage the two pins of FPC charger.**



#### INSTALLATION


Mount a new Magnetic charger connector by fingers.



Check and press the two pins into its cavities by using the Front Opening Tool.

**Be careful! Do not damage the two pins of FPC charger.**

Then use Side Panel press, Side Panel Press Head and Charge connector press pad with the force of 60N for five seconds. According to 1003-9107 Tool Catalogue – mechanical and document Side Panel press Instruction for use.



## Replacement

### 4.40 PBA Cellular Sub

*Follow the 3.1 – 3.2, 3.6 and 3.8 Disassembly instructions!*

*Carry out the Removal as described below!*



*Prepare a new PBA Cellular Sub!*

*Carry out the Installation as described below!*

*Follow the 5.3, 5.5 and 5.9 - 5.11 Reassembly instructions!*


#### REMOVAL

Remove the PBA Cellular Sub with the Front Opening Tool.



#### INSTALLATION

Place a new PBA Cellular Sub using fingers in the cavity of Loudspeaker Holder.



## Replacement

### 4.41 PBA WLAN Sub


*Follow the 3.1 – 3.2, 3.6 and 3.8 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new PBA WLAN Sub!*


*Carry out the Installation as described below!*

*Follow the 5.3, 5.5 and 5.9 - 5.11 Reassembly instructions!*




#### REMOVAL

Remove the PBA WLAN Sub with the Front Opening Tool.



#### INSTALLATION

Place a new PBA WLAN Sub using fingers in the cavity of Loudspeaker Holder.



## Replacement

### 4.42 Plate Contact RF A


*Follow the 3.1 - 3.6 and 3.9 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Holder Magnetic Charger Connector!*

*Carry out the Installation as described below!*

Follow the 5.2, 5.5 and 5.9-5.11 Reassembly instructions!




#### REMOVAL

Detach to remove the Holder Magnetic Charger Connector with a pair of tweezers.

#### INSTALLATION

Place a new Holder Charger Connector using a pair of tweezers



## Replacement

### 4.43 Power Key

*Follow the 3.1 – 3.10 Disassembly instructions!*

*Follow the 4.35, 4.18 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Power Key!*

*Carry out the Installation as described below!*

*Follow the 4.18, 4.35 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Pull to remove the Power Key with fingers

#### INSTALLATION

Insert a new Power Key with fingers





## Re-Assembly

### 4.44 RF Cable B

*Follow the 3.1 - 3.2, 3.6 and 3.9 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new RF Cable B!*



*Carry out the Installation as described below!*

*Follow 5.5 and 5.9-5.11 Reassembly instructions!*

#### REMOVAL


Release the RF Cable B with the Flex Film Assembly Tool.

**Note! Careful not to break the two connectors!**




#### INSTALLATION

Place a new RF Cable B using a Flex Film Assembly Tool.



Connect the two connectors with fingers

**Note! Important that the silver parts of the RF Cable B is placed in the two sockets.**



## Replacement

### 4.45 SD Cap

*Carry out the Removal as described below!*

*Prepare a new SD Cap!*

*Carry out the Installation as described below!*



#### REMOVAL

Detach to remove the SD Cap with fingers

#### INSTALLATION

Place a new SD Cap with fingers and a pair of tweezers



## Replacement

### 4.46 Sheet Conductive Charger FPC

*Follow the 3.1-3.10 Disassembly instructions!*

*Follow the 4.30 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Sheet Conductive Charger FPC!*

*Follow the 4.30 Installation instructions!*

*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Sheet Conductive Charger FPC with Nylon Pointer.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Sheet Conductive Charger FPC using a Flex Film Assembly Tool.



## Replacement

### 4.47 Sheet Conductive Relay FPC

*Follow the 3.1-3.10 Disassembly instructions!*

*Follow the 4.32 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Sheet Conductive Relay FPC!*

*Follow the 4.32 Installation instructions!*

*Carry out the Installation as described below!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Sheet Conductive Charger FPC with Nylon Pointer.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Sheet Conductive Charger FPC using a Flex Film Assembly Tool.



## Replacement

### 4.48 Sheet Thermal A


*Follow the 3.1-3.7 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Sheet Thermal A!*

*Carry out the Installation as described below!*

*Follow the 5.4 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Sheet Thermal A with Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Sheet Thermal A using a Flex Film Assembly Tool



## Replacement

### 4.49 Sheet Thermal B


*Follow the 3.1-3.7 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Sheet Thermal B!*

*Carry out the Installation as described below!*

*Follow the 5.4 - 5.11 Reassembly instructions!*




#### REMOVAL

Detach to remove the Sheet Thermal B with Dentist Hook.

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Sheet Thermal B using a Flex Film Assembly Tool



## Replacement

### 4.50 Sheet WP 2<sup>nd</sup> Mic

*Follow the 3.1 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Sheet WP 2<sup>nd</sup> Mic!*

*Carry out the Installation as described below!*


*Follow the 5.10 - 5.11 Reassembly instructions!*



#### REMOVAL


Detach to remove the Sheet WP 2<sup>nd</sup> Mic with Dentist Hook.

**Scrap! Not to be reused!**



#### INSTALLATION

Place a new Sheet WP 2<sup>nd</sup> Mic using a Flex Film Assembly Tool



## Replacement

### 4.51 Sheet WP Check


*Follow the 3.1-3.10 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Sheet WP Check!*

*Carry out the Installation as described below!*


*Follow the 5.1 - 5.11 Reassembly instructions!*



#### REMOVAL


Detach to remove the Sheet WP Check with Dentist Hook.

**Scrap! Not to be reused!**



#### INSTALLATION

Place a new Sheet WP Check using a Flex Film Assembly Tool





## Replacement

### 4.52 SIM Cap

*Carry out the Removal as described below!*

*Prepare a new SIM Cap!*

*Carry out the Installation as described below!*




#### REMOVAL

Detach to remove the SIM Cap with fingers

#### INSTALLATION

Place a new SIM Cap with fingers and a pair of tweezers




## Replacement

### 4.53 Speaker Panel

*Carry out the Removal as described below!*

*Prepare a new Speaker Panel!*

*Carry out the Installation as described below!*




#### REMOVAL

Detach to remove the Speaker Panel with the Dentist Hook...

**Scrap! Not to be reused!**

#### INSTALLATION

Place a new Speaker Panel with fingers and press for 10 sec over the panel.



## Replacement

### 4.54 Tray Core Unit Label

*Follow the 3.1-3.7 Disassembly instructions!*

*Follow the 4.25 Removal instructions!*

*Carry out the Removal as described below!*

*Prepare a new Tray Core Unit Label!*



*Carry out the Installation as described below!*

*Follow the 4.25 Installation instructions!*

*Follow the 5.4 - 5.11 Reassembly instructions!*


#### REMOVAL

Open the SIM Cap with fingers. Pull out the Tray Core Unit Label with fingers and lift up the Tray Core Unit Label around the arrows before releasing it.




#### INSTALLATION

Place a new Tray Core Unit Label and put it in the cavity.



Close the SIM Cap.




## Replacement

### 4.55 USB Cap

*Carry out the Removal as described below!*

*Prepare a new USB Cap!*

*Carry out the Installation as described below!*



#### REMOVAL

Detach to remove the USB Cap with fingers

#### INSTALLATION

Place a new USB Cap with fingers and a pair of tweezers



## Replacement

### 4.56 USB Holder


*Follow the 3.1-3.7 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new USB Holder!*

*Carry out the Installation as described below!*

*Follow the 5.4 - 5.11 Reassembly instructions!*



#### REMOVAL

Detach to remove the USB Holder with fingers

#### INSTALLATION

Place a new USB Holder with fingers.

## Replacement

### 4.57 Vibrator

*Follow the 3.1 - 3.2 Disassembly instructions!*

*Carry out the Removal as described below!*

*Prepare a new Vibrator!*


*Carry out the Installation as described below!*

*Follow the 5.9 - 5.11 Reassembly instructions!*




#### REMOVAL

Disconnect the connector of Vibrator by using a Front Opening Tool.




Detach to remove the Vibrator with Front Opening Tool



#### INSTALLATION

Place a new Vibrator into the cavity using fingers and connect to Main PBA



## Replacement

### 4.58 Volume Key

*Follow the 3.1-3.10 Disassembly instructions!*

*Follow the 4.35 and 4.18 Removal instructions!*


*Carry out the Removal as described below!*

*Prepare a new Volume Key!*

*Carry out the Installation as described below!*

*Follow the 4.18 and 4.35 Installation instructions!*

*Follow the 5.1 - 5.11 Reassembly instructions!*




#### REMOVAL

Pull to remove the Volume Key with fingers

#### INSTALLATION

Insert a new Volume Key with fingers



## Replacement


### 4.59 Board Swap - Replacement

*Follow the 3.1 to 3.7 Disassembly instructions!*

*Follow the 4.23 and 4.56 Removal instructions!*

**Reuse the Camera, Chat Camera and Battery!**

Replace the Swap Board.



*Follow the 4.23 and 4.56 Installation instructions!*

*Follow the 5.4 to 5.11 Reassembly instructions!*

Press the Key On/Off to power on the phone, place unit on flat desk and wait 4 minutes until system boot up has been completed.

**Please DO NOT move the phone during starting up until "Select Language" menu is shown on the display!**

After "Select Language" menu, turn off the phone.

**Follow the Calibration chapter 3.1 and 3.2 in 1277-9815**

**Test Instruction – mechanical**




## 5 Re-Assembly

### C6902, C6903, C6906, L39h

The Re-assembly is done to the following modules:

1. Front Cover (a) and Main Frame Assy (b)
2. RF Cable A
3. Loudspeaker Holder
4. Main PBA
5. Battery
6. SIM Tray
7. Shield Camera
8. Camera
9. Rear Cover Assy
10. Sheet Battery
11. Window Back



### 5.1 Front Cover and Main Frame Assy

*Follow the 4.17 removal and installation instruction to replace a new Adhesive WP Main Frame Assy*

Place the Front Cover on the Main Frame Assy




Press with fingers to secure the contact of adhesive between Front Cover and Main Frame Assy




## Re-Assembly

### 5.2 RF Cable A


Place the RF Cable A to the Main Frame Assy



Place a new Cable RF Cable A using a Flex Film Assembly Tool.




Note! Important that the silver parts of the RF Cable A is placed in the three sockets.




### 5.3 Loudspeaker Holder

Place the Loudspeaker Holder to Main Frame Assy




## Re-Assembly

Use fingers to secure the position of Loudspeaker Holder




Use fingers to secure positions of RF Cable A and RF Cable B




### 5.4 Main PBA

Place the Main PBA gently into the cavity




Use fingers to secure position of Main PBA




## Re-Assembly

Press with fingers to secure the position of BtB connectors, RF Cable A and RF Cable B



### 5.5 Battery

Place the Battery gently into the cavity




Use fingers to secure the position of the Battery




### 5.6 SIM Tray

Open SIM Cap.




## Re-Assembly

Use with fingers to secure the SIM Tray then close SIM Cap




### 5.7 Shield Camera

Use a pair of tweezers to position Shield Camera into the cavity




Secure the position with a pair of tweezers



### 5.8 Camera


Use fingers to position Camera into the cavity






## Re-Assembly

Press with fingers to secure the contact of Camera



### 5.9 Rear Cover Assy

Press with fingers to secure the contact of Battery




**Follow the 4.15 removal and installation instruction to replace a new Adhesive WP Cover Rear**

Use Isopropyl Alcohol - 99 % for clean around the edges of Main Frame Assy before assembly Rear Cover Assy



Place the Rear Cover Assy on the frame



Press with fingers to secure the contact of Chat Camera



## Re-Assembly





Upper inlay = Rear Cover Press Inlay

Lower inlay = Bottom Press Inlay

Place the phone in the Bottom Press Inlay and follow the instruction in 1003-9107 Tool Catalogue – mechanical and document Toothed Rack Press Instruction for use.

Press it with a pressure value of 483N +/- 50 N / 10 sec  
(pressure value is adjust from 600N because of the weight of the press fixture)

Apply 13 Ncm torque when tightening the Screw 3.5x1.4 with  
Torx Bits T4



## Re-Assembly

### 5.10 Sheet Battery


Use a Flex Film Assembly Tool and fingers for assembly the Sheet Battery on the Battery



### 5.11 Window Back

*Follow the 4.18 removal and installation instruction to replace a new Adhesive WP Window Back*

Use Isopropyl Alcohol - 99 % for clean around the edges of Rear Cover Assy before assembly Window Back



Place the Window Back on the Rear Cover Assy.



Make sure of an good alignment so the Window Back is centered







## Re-Assembly

Upper inlay = Window Back Press Inlay

Lower inlay = Bottom Press Inlay

Place the phone in the Bottom Press Inlay and follow the instruction in 1003-9107 Tool Catalogue – mechanical and document Toothed Rack Press Instruction for use.

Press it with a pressure value of  $483\text{N} \pm 50\text{N}$  / 10 sec.  
(pressure value is adjust from 600N because of the weight of the press fixture)



## 6 Revision History

Rev.	Date	Changes / Comments
1	2013-Sept-05	First Release
2	2013-Sept-12	System Problem